

AGUARDIO LEAK SENSOR

Placement & Activation Guide



1. Placement

- 1.1 In the package
- 1.2 Registration of the Leak Sensor
- 1.2 Activation of the Leak Sensor
- 1.3 Placement of the Leak Sensor

2. Aguardio App Set Up


- 2.2 Download the APP
- 2.2 Log in
- 2.3 Activate the APP
- 2.4 Collect the data

3. Access data in Aguardio HUB

1. Placement

1.1 In the package

Each individual package contains a Leak Sensor and a plastic tie. For larger quantity packages, Leak Sensors will be individually packed in plastic bags and accompanied by separately packed plastic ties.




1.2 Registration of the Leak Sensor

Prior to the physical installation, we kindly request that you register the Leak Sensor location. This registration is essential for effective leak detection. *Note: This step can also be completed or adjusted later in the process; However, we recommend not delaying.*

1.3 Activation of the Leak Sensor

Activate the Leak Sensor by pressing and holding the side button for ten seconds. before placing it on the pipework. This step will enable the collection of fresh data from the beginning.



[Click here to download registration form](#)

1.4 Placement of the Leak Sensor

Select sensor location on the toilet's water inlet pipe:


- Sensor should only be fitted on copper or steel pipework
- Do not fit Leak Sensor on plastic pipework
- Ensure that the sensor sponge is fitted against the pipe, or metal surface

Properly secure the plastic tie:

- Place the plastic tie loosely around the inlet pipe allowing enough room to position sensor inside it
- Gradually tighten the plastic tie to firmly affix the sensor to the pipework.

Tip: If you need extra security to fasten the Leak Sensor, use any type of generic zip tie as an additional measure.

A. PLACE LEAK SENSOR HERE



B. PLACE LEAK SENSOR HERE

Positioning of the Leak Sensor

[Click here to see video guide](#)

Or scan QR- code:



For wall-mounted toilet:

[Click here to see video guide \(wall-mounted\)](#)

AGUARDIO LEAK SENSOR

Placement & Activation Guide

2. Aguardio App setup




2.1 Download Aguardio Connected Solutions app



[See APP video guide here](#)

Or scan QR code:



-
- Desktop links:
 
-  **Aguardio Connected Solutions**

2.2 Log in to the APP



[Click here to download APP guide](#)

Log in to the app with these credentials:

Username: setup@aguardio.com

Password: SuperDemo


2.3 Activate the APP

Activate "Gateway" mode on your device

Remember to enable "Bluetooth" mode on your device for the APP to work



Press the "user- menu" in the top right corner.



Press the "user- menu" in the top right corner.

AGUARDIO LEAK SENSOR

Placement & Activation Guide

2.4 Collect data

Click "Collect Data"

Choose the desired Bluetooth range by clicking on the blue icon in the upper-right corner. If you are close to sensors, we recommend starting from -65 dBm. Wait until the data from the detected sensors are collected, then increase the Bluetooth range incrementally. This approach allows you to collect data from the nearest sensors first, ensuring better and faster data retrieval.

After successfully collecting data, the sensor will be moved to the bottom of the list, categorized under 'Saved in Cloud.' There, you will see only a green light and a timestamp indicating the last synchronization of data, referred to as 'Last sync'.

If you want to clear the list of sensors that you collected data from, please, double-click on the blue pulsating circle.

Useful and practical tips for collecting data




[Click here to download APP guide](#)

- Set the app on -65dBm, then the app collects data from the nearest sensors first. If the app stops detecting new sensors, increase the Bluetooth range incrementally. This can be done by tapping the blue icon in the upper-right corner of the app. After increasing the range, continue moving at a gentle pace. Pause briefly to allow the app to collect data from any newly visible sensors.
- If you set the app to -95 or -128 dBm, it will detect all the sensors within the Bluetooth range. If you have many sensors installed, this can overload the app, causing difficulties in establishing connections with the sensors.
- If you see a long list of sensors, perhaps 10-20, all showing as 'green' in the app, it might become difficult to manage further data collection effectively. In this case, it's advisable to double-click on the blue blinking circle, to clear the view.
- If your sensors show a red indication or stands without any indication, try to move closer to the sensor, or increase a Bluetooth range in the app.

dBm- number

In Aguardio app you can select the wanted Bluetooth range. It allows you to choose between -65dBm, -75dBm, -85dBm, -90dBm, -95dBm, & -128 dBm. Please see the table below for reference.

The closer the value is to 0, the stronger the signal.



In the range of -85 dBm and below, you have the strongest signal for data collection. Between -85 and -95 dBm, it can be difficult in some cases to collect data. Above -95dBm, it is most likely not possible.

To get a stronger Bluetooth signal, try the following:

- Move closer to the sensor
- Eliminate obstacles that could disrupt the Bluetooth connection, for example, open any doors that could be disrupting it.

AGUARDIO LEAK SENSOR

Placement & Activation Guide

3. Access data in Aguardio HUB

To learn more about how to access your bathroom data & use it to optimise building maintenance, please download "Aguardio HUB" guide.



[Click here to
download HUB guide](#)